


Characteristic Curves


FOR FT18M - FT18 - FT18EL - FTQ TYPES




FT18EL-CP




FT18M-CP2 / FT18-AP2




FT18M-CP4 / FT18-AP4




FT18M-CR / FT18-AR / FT18EL-CR




FT18M-CAR / FT18-AAR / FT18EL-CAR




FT18M-CBE + FT18M-CBR
FT18-ABE + FT18-ABR
FT18EL-CBE + FT18EL-CBR




FTQ-CP / FTQ P-R



FTQ-CR / FTQ R-R



FTQ-CAR / FTQ AR-R



FTQ-CBE + FTQ-CBR
FTQ-BE-R + FTQ-BR-R

